



MODEL H8372 VARIABLE POWER SPOTTING SCOPE INSTRUCTIONS

Introduction

This high quality spotting scope is great for viewing wildlife and down range targets.

Inventory

After all the parts have been removed from the box, use the **Parts Breakdown** on the back of this page to inventory the parts.

⚠ WARNING

Viewing the sun or any source of strong light with this scope could cause temporary or permanent damage to the eyes. Never use this scope to view sources of strong light.

Specifications

Magnifying Power..... 9–27
Objective Lens Diameter..... 50mm
Ocular Angle..... 45°
Tripod Mount Thread..... 1/4"-20
Minimum Viewing Distance 20 ft.
Weight w/o Tripod, Caps, or Case 1 1/4 lbs.

Operation

1. Attach spotting scope to tripod.
2. Unscrew eyepiece lens cap from rubber eyecup, and remove objective lens cap.



Figure 1. Model H8372 components.

Note: The edge of the rubber eyecup (see **Figure 1**) can be folded down to view the full field when wearing eyeglasses.

3. To focus, slowly rotate focus ring until object becomes clear.

Note: The minimum viewing distance is approximately 20 feet.

4. Change magnification by rotating zoom ring.

Note: You may need to re-focus after changing magnification.

Care & Storage

When not in use, install the eyepiece and objective lens caps and place the scope in the protective case. Store the scope and tripod in a dry, room-temperature environment.

NOTICE

Natural skin oil can permanently damage the lens coating, causing a reduction in viewing quality. Never touch the lenses with your fingers.

If you need help with your new item, call our Tech Support at: (570) 546-9663.


Cleaning

Use compressed air or a lens brush to remove any dust or debris from the lenses. To remove dirt from the lenses, use a soft, clean *cotton* cloth and lightly rub in a circular motion from the center outward. For a more thorough cleaning, apply a photographic-type lens fluid to the cleaning cloth—not directly on the lens.

NOTICE

Using coarse fiber cloth or any paper product can permanently scratch the lens surface. Use only soft, cotton cloth to clean the lenses.

Parts Breakdown & List



REF	PART #	DESCRIPTION
1	PH8372001	SPOTTING SCOPE 9-27X50MM
2	PH8372002	RUBBER EYECUP
3	PH8372003	TRIPOD

REF	PART #	DESCRIPTION
4	PH8372004	EYEPIECE CAP
5	PH8372005	OBJECTIVE LENS CAP
6	PH8372006	PROTECTIVE CASE