


SECTION 9: PARTS

Main Parts Breakdown 1000 Series



Main Parts List

REF	PART #	DESCRIPTION
1001	P33581001	DRAW BAR 7/16-20 X 402MM
1002	P33581002	SPINDLE LOCK NUT
1003	P33581003	SPINDLE PULLEY
1004	P33581004	BELT BOTTOM COVER
1005	P33581005	SWITCH
1006	P33581006	SPINDLE TAPER SLEEVE
1007	P6009	BALL BEARING 6009ZZ
1008	P33581008	BEARING SPACER
1009	P33581009	QUILL STOP ADJ ROD M12 X 235
1010	PR25M	INT RETAINING RING 47MM
1011	P33581011	HEAD BODY
1012	P33581012	RUBBER FLANGE
1013	P33581013	FEED BASE
1014	P33581014	LOCK NUT M30-1.5
1015	P33581015	TAPER BEARING 30205/P5
1016	P33581016	SPINDLE SLEEVE
1017	P33581017	SPINDLE SHAFT
1018	P33581018	TAPER BEARING 30207/P5
1019	P33581019	BEARING CAP
1020	P33581020	CUTTER ARBOR R8
1020-1	PFH30M	FLAT HD SCR M5-.8 X 8
1020-2	P33581020-2	KEY
1021	P33581021	CHUCK ARBOR JT#3-R8
1022	P33581022	GRIP
1023	PR56M	EXT RETAINING RING 45MM
1024	P33581024	QUILL LOCK HANDLE
1025	P33581025	COLLAR
1026	P33581026	THREADED COLLAR
1027	P33581027	SCREW KEY
1035	P33581035	BEARING SPACER
1039	P33581039	QUILL HANDLE
1040	P33581040	QUILL HANDLE KNOB M12-1.25
1044	P33581044	MICRO ADJUSTING INDICATOR
1045	P33581045	WORM COVER
1046	P6202	BALL BEARING 6202ZZ
1047	P33581047	WORM SHAFT
1050	P33581050	LOCK HANDLE
1051	P33581051	SPECIAL WING SCREW
1052	P33581052	HEAD BOLT M16-2 X 150
1055	P33581055	GRADUATED DIAL

REF	PART #	DESCRIPTION
1056	P33581056	SPACER
1057	P33581057	NAME PLATE
1058	P33581058	HEAD HANDLE
1059	P33581059	WORM SHAFT
1060	P33581060	WORM
1061	P33581061	SHAFT
1062	P33581062	COMPRESSION SPRING
1063	P33581063	PIN
1066	P33581066	MOTOR MOUNT
1067	P33581067	MOTOR 2HP 110/220V
1067-1	P33581067-1	MOTOR FAN
1067-2	P33581067-2	MOTOR HOUSING
1067-3	P33581067-3	JUNCTION BOX
1067-4	P33581067-4	S CAPACITOR 400M 265V 2 X 3-3/4
1067-5	P33581067-5	R CAPACITOR 40M 450V 2 X 3-3/4
1067-6	P33581067-6	CAPACITOR COVER
1067-7	P33581067-7	CENTRIFUGAL SWITCH
1067-8	P33581067-8	CONTACT PLATE
1069	P33581069	BELT TOP COVER
1069-1	P33581069-1	DRAWBAR COVER
1069-2	P33581069-2	PLASTIC COVER
1070	P33581070	MOTOR PULLEY
1071	P33581071	V-BELT 5L330
1072	P6204	BALL BEARING 6204ZZ
1073	P33581073	IDLER PULLEY
1074	PVB40	V-BELT B-40 5L400
1075	P33581075	IDLER PULLEY SHAFT
1076	P33581076	IDLER PULLEY BASE
1077	P33581077	CLIP PLATE
1079	P33581079	RUBBER COLLAR
1085	P33581085	KNOB M6-1 X 14
1086	P33581086	FACE MILL 80MM
1087	P33581087	DRILL CHUCK JT#3 0"-1/2"
1091	P33581091	STOP NUT M20-1.5 X 23
1092	P33581092	STOP BLOCK
1093	PLN07M	LOCK NUT M16-2
1094	P33581094	SUPPORT BASE
1095	P33581095	DEPTH STOP KNOB
1096	P33581096	FRONT COVER PLATE
1097	P33581097	PROTECTION PIECE




Main Parts List (continued)

REF	PART #	DESCRIPTION
1101	P33581101	COLUMN GEAR COVER
1102	P33581102	LIMIT PLATE
1103	P33581103	SPRING COVER
1104	P33581104	COILED SPRING
1105	P33581105	SPRING BASE
1106	P33581106	PINION SHAFT
1107	P33581107	FEED COVER
1108	P33581108	WORM GEAR BOX
1109	P33581109	COMPRESSION SPRING
1110	P33581110	SPRING BASE
1110-1	P33581110-1	CLUTCH KNOB
1131	PB03M	HEX BOLT M8-1.25 x 16
1132	PW01M	FLAT WASHER 8MM
1133	PS16M	PHLP HD SCR M8-1.25 X 16
1134	PB39M	HEX BOLT M6-1 X 50
1135	PN01M	HEX NUT M6-1
1136	PRP64M	ROLL PIN 3 X 18
1137	PLW16M	LOCK WASHER 30MM
1139	PS76M	PHLP HD SCR M8-1.25 X 12
1140	PRP44M	ROLL PIN 3 X 10
1141	PN02M	HEX NUT M10-1.5
1142	PK70M	KEY 8 X 8 X 12
1143	PSB14M	CAP SCREW M8-1.25 X 20

REF	PART #	DESCRIPTION
1145	PSS31M	SET SCREW M5-.8 X 8
1146	P33581146	KNURLED SCREW M5-.8 X 12
1147	PSB24M	CAP SCREW M5-.8 X 16
1148	PR05M	EXT RETAINING RING 15MM
1150	PN13M	HEX NUT M16-2
1151	PW08M	FLAT WASHER 16MM
1152	PHTEK11M	TAP SCREW M3 X 8
1153	PSS14M	SET SCREW M8-1.25 X 12
1155	PSB02M	CAP SCREW M6-1 X 20
1156	PB07M	HEX BOLT M8-1.25 X 25
1157	P33581157	HEX BOLT M12-1 X 25
1158	PN03M	HEX NUT M8-1.25
1159	P33581159	KEY 8 X 40
1160	PB26M	HEX BOLT M8-1.25 X 30
1161	PW01M	FLAT WASHER 8MM
1162	P33581162	OUTLINE BUSHING
1163	PS76M	PHLP HD SCR M8-1.25 X 12
1164	PHTEK11M	TAP SCREW M3 X 8
1185	P33581185	DEPTH STOP INDICATOR
1187	PW01M	FLAT WASHER 8MM
1188	PS39M	PHLP HD SCR M8-1.25 X 10
1190	P33581190	DOWNFEED CONTROL KNOB
1190-1	P33581190-1	KNOB HANDLE



Base Parts Breakdown 1000 Series




Base Parts List

REF	PART #	DESCRIPTION
1146	P33581146	KNURLED SCREW M5-.8 X 12
1201	P33581201	TABLE HANDLE WHEEL
1202	P33581202	DIAL CLUTCH
1203	P8103	THRUST BEARING 8103
1204	P33581204	SQUARE FLANGE
1205	P33581205	CROSSFEED LEAD SCREW
1206	P33581206	BASE
1207	P33581207	CROSS SLIDE GIB
1208	P33581208	COLUMN BASE
1209	P33581209	COLUMN FLANGE RING
1210	P33581210	RACK
1211	P33581211	COLUMN HEAD
1212	P33581212	GIB STRIP BOLT
1213	P33581213	LEAF SCREW
1214	P33581214	MOVABLE FIXED BLOCK
1215	P33581215	CROSS SLIDE LEAD SCREW NUT
1216	P33581216	CENTER BASE
1217	P33581217	WAY COVER BRACKET
1218	P33581218	WAY COVER
1219	P33581219	WAY COVER BRACKET

REF	PART #	DESCRIPTION
1220	P33581220	TABLE CLUTCH
1222	P33581222	LEFT FLANGE
1223	P33581223	LEAD SCREW NUT
1224	P33581224	LONGITUDINAL LEAD SCREW
1226	P33581226	RIGHT FLANGE
1227	P33581227	LONGITUDINAL GIB
1228	P33581228	TABLE
1229	P33581229	FIXED BLOCK
1230	P33581230	MOVABLE FIXED RING
1331	PB06M	HEX BOLT M8-1.25 X 12
1343	PSB31M	CAP SCREW M8-1.25 X 25
1345	PSS21M	SET SCREW M8-1.25 X 25
1366	PRP30M	ROLL PIN 5 X 50
1367	P33581367	GRADUATED COLLAR
1368	P33581368	BALL OILER
1372	PB165M	HEX BOLT M16-2 X 60
1373	PLW10M	LOCK WASHER 16MM
1374	PSB33M	CAP SCREW M5-.8 X 12
1375	PSB14M	CAP SCREW M8-1.25 X 20
1376	PSB26M	CAP SCREW M6-1 X 12



Label Breakdown and List



REF	PART #	DESCRIPTION
1401	P33581401	MACHINE ID LABEL
1402	P33581402	WEAR GLASSES LABEL
1403	P33581403	ENTANGLEMENT LABEL
1404	PLABEL-14	ELECTRICITY LABEL

REF	PART #	DESCRIPTION
1405	PPAINT-1	GRIZZLY GREEN TOUCH UP PAINT
1406	P33581406	READ MANUAL LABEL
1407	P33581407	DISCONNECT POWER LABEL
1408	G9987	GRIZZLY NAMEPLATE

WARNING

Safety labels warn about machine hazards and ways to prevent injury. The owner of this machine **MUST** maintain the original location and readability of the labels on the machine. If any label is removed or becomes unreadable, **REPLACE** that label before using the machine again. Contact Grizzly at (800) 523-4777 or www.grizzly.com to order new labels.

