


# SECTION 9: PARTS

## Main Breakdown



# Main Parts List

| REF | PART #     | DESCRIPTION                  |
|-----|------------|------------------------------|
| 1   | P9717001   | WHEEL COVER LH OUTER         |
| 2   | P9717002   | SPINDLE NUT LH M12-1.75 X 22 |
| 3   | P9717003   | WHEEL DISC                   |
| 4   | P9717004   | SPARK ARRESTOR               |
| 5   | P9717005   | EYE SHIELD                   |
| 6   | P9717006   | WHEEL COVER LH INNER         |
| 7   | P9717007   | WORK REST LH                 |
| 8   | P6202      | BALL BEARING 6202ZZ          |
| 9   | P9717009   | BEARING HOUSING              |
| 10  | P9717010   | ROTOR                        |
| 11  | PWRCRD110L | POWER CORD 16AWG X 3C X 73"L |
| 12  | P9717012   | STATOR                       |
| 13  | P9717013   | WAVY WASHER Z02              |
| 14  | P9717014   | STRAIN RELIEF                |
| 15  | P9717015   | MOUNTING PLATE               |
| 16  | P9717016   | MOTOR BODY                   |
| 17A | P9717017A  | WARNING LABEL                |
| 17B | P9717017B  | NAMEPLATE LABEL              |
| 18  | P9717018   | WHEEL COVER RH INNER         |
| 19  | P9717019   | WHEEL RIM GUARD              |
| 20  | P9717020   | WORK REST RH                 |
| 21  | P9717021   | GRINDING WHEEL A-60Q         |
| 22  | P9717022   | WHEEL FLANGE                 |

| REF | PART #   | DESCRIPTION                        |
|-----|----------|------------------------------------|
| 23  | P9717023 | SPINDLE NUT RH M12-1.75 X 22       |
| 24  | P9717024 | WHEEL COVER RH OUTER               |
| 25  | P9717025 | BASE                               |
| 26  | P9717026 | SWITCH PROTECTOR                   |
| 27  | P9717027 | SWITCH                             |
| 29  | PC040F   | R CAPACITOR 40M 250V 1-3/8 X 2-3/8 |
| 30  | P9717030 | BASE PLATE                         |
| 31  | P9717031 | RUBBER FOOT                        |
| 32  | P9717032 | GRINDING WHEEL A-36Q               |
| 34  | PW02M    | FLAT WASHER 5MM                    |
| 35  | PLW01M   | LOCK WASHER 5MM                    |
| 36  | PS05M    | PHLP HD SCR M5-.8 x 8              |
| 37  | PS07M    | PHLP HD SCR M4-.7 X 8              |
| 38  | PN06M    | HEX NUT M5-0.8                     |
| 39  | PS54M    | PHLP HD SCR M5-.8 X 45             |
| 40  | PS09M    | PHLP HD SCR M5-.8 X 10             |
| 41  | PS08M    | PHLP HD SCR M5-.8 X 12             |
| 42  | PB06M    | HEX BOLT M8-1.25 X 12              |
| 43  | PW01M    | FLAT WASHER 8MM                    |
| 44  | PLW04M   | LOCK WASHER 8MM                    |
| 44A | PB18M    | HEX BOLT M6-1 X 15                 |
| 45  | PW03M    | FLAT WASHER 6MM                    |
| 46  | P9717046 | CAPACITOR MOUNTING STRAP           |

## WARNING

Safety labels help reduce the risk of serious injury caused by machine hazards. If any label comes off or becomes unreadable, the owner of this machine **MUST** replace it in the original location before resuming operations. For replacements, contact (800) 523-4777 or [www.grizzly.com](http://www.grizzly.com).

