



Parts Breakdown



Parts List

REF	PART #	DESCRIPTION
1	PH8203001	BASE PLATE
2	PH8203002	ANGLE BRACKET
3	PH8203003	SWIVEL SLEEVE
4	PH8203004	SPECIAL CAP SCREW
5	PH8203005	CALIBRATING DEVICE BASE
6	PH8203006	CALIBRATING PLATE
7	PH8203007	SPECIAL SET SCREW
8	PH8203008	COLLET HOLDER
9	PH8203009	LOCK RING
10	PH8203010	COMPRESSION SPRING
11	PH8203011	FLANGE
12	PH8203012	CLEANING BRUSH
13	PH8203013	MOTOR BRACKET
14	PH8203014	ADJUSTING BLOCK
15	PH8203015	FAN
16	PH8203016	GRINDING WHEEL CBN 170
17	PH8203017	MOTOR 110V, 1/6 HP
18	PH8203018	BALLAST
19	PH8203019	FOOT
20	PH8203020	CALIBRATING DEVICE COVER
21	PH8203021	GRINDING WHEEL COVER
22	PH8203022	MOTOR COVER
24	PH8203024	HANDLE
25	PH8203025	CALIBRATING DIAL
26	PSB41M	CAP SCREW M4-.7 X 14
27	PSB06M	CAP SCREW M6-1 X 25
28	PSB20M	CAP SCREW M5-.8 X 14
29	PSB41M	CAP SCREW M4-.7 X 14
30	PSB33M	CAP SCREW M5-.8 X 12
31	PSB20M	CAP SCREW M5-.8 X 14
32	PSB20M	CAP SCREW M5-.8 X 14
33	PSB50M	CAP SCREW M5-.8 X 10
34	PSS31M	SET SCREW M5-.8 X 8

REF	PART #	DESCRIPTION
35	PSBS24M	BUTTON HD CAP SCR M4-.7 X 10
36	PSB03M	CAP SCREW M5-.8 X 8
37	PSB03M	CAP SCREW M5-.8 X 8
38	PSB14M	CAP SCREW M8-1.25 X 20
39	PH8203039	SWITCH
40	PH8203040	COLLET 1/8"
41	PH8203041	COLLET 5/32"
42	PH8203042	COLLET 3/16"
43	PH8203043	COLLET 1/4"
44	PH8203044	COLLET 9/32"
45	PH8203045	COLLET 5/16"
46	PH8203046	COLLET 3/8"
47	PH8203047	COLLET 25/64"
48	PH8203048	COLLET 7/16"
49	PH8203049	COLLET 15/32"
50	PH8203050	COLLET 1/2"
51	PH8203051	POWER CORD
52	PH8203052	STRAIN RELIEF
53	PSS51M	SET SCREW M4-.7 X 8
54	PH8203054	FUSE 5A
55	PH8203055	LIMIT SWITCH
100	PH8203100	READ MANUAL LABEL 2-3/4" X 1-1/2"
101	PH8203101	DISCONNECT POWER LABEL 2-3/4" X 1-1/2"
102	PH8203102	KEEP COVER CLOSED LABEL 2-3/4" X 1-1/2"
103	PH8203103	MACHINE ID LABEL
104	PH8203104	ANGLE SCALE LABEL
105	PH8203105	CALIBRATING DIAL LABEL
106	PH8203106	DRILL DIAMETER LABEL
107	PH8203107	ELECTRICITY LABEL
108	PH8203108	GRIZZLY GREEN TOUCH UP PAINT
109	PH8203109	BLACK TOUCH UP PAINT
110	PH8203MAN	H8203 MANUAL 11/7

WARNING

Safety labels warn about machine hazards and ways to prevent injury. The owner of this machine **MUST** maintain the original location and readability of the labels on the machine. If any label is removed or becomes unreadable, **REPLACE** that label before using the machine again. Contact Grizzly at (800) 523-4777 or www.grizzly.com to order new labels.

