


Parts



REF	PART #	DESCRIPTION
1	PT26746001	DRUM LID
2	PT26746002	COMPRESSION SPRING
3	PT26746003	FOLLOWER PLATE
4	PT26746004	DRUM
5	PT26746005	PUMP RETAINING BOLT
6	PT26746006	COMPRESSION SPRING
7	PT26746007	STEEL BALL 12MM
8	PT26746008	BASE
9	PT26746009	GREASE OUTLET M14
10	PT26746010	GREASE INLET
11	PT26746011	PUMP
12	PT26746012	COMPRESSION SPRING
13	PT26746013	LOCKING PLATE
14	PT26746014	PEDAL LEVER
15	PT26746015	FOOT PEDAL

REF	PART #	DESCRIPTION
16	PT26746016	STAND
17	PT26746017	HEX BOLT M8-1 X 40
18	PT26746018	HEX BOLT M6-1 X 25
19	PT26746019	HEX NUT M8-1
20	PT26746020	LOCK NUT M6-1
21	PT26746021	LOCK WASHER 8MM
22	PT26746022	LOCK NUT M8-1
23	PT26746023	MACHINE ID LABEL
24	PT26746024	GRIZZLY.COM LABEL
25	PT26746025	GRIZZLY GREEN TOUCH-UP PAINT
29	PT26746029	GREASE GUN
30	PT26746030	HIGH PRESSURE HOSE 5700-PSI
31	PT26746031	HANDLE
32	PT26746032	WHEEL

